

Installing Trimble® Positions™ ArcPad® Extension

October 2, 2014

In this support note, we will give you the steps on installing the Positions ArcPad extension. Before you get started, you will want to find the latest version of Positions ArcPad Extension that is compatible with the ESRI® ArcPad installed to your GPS device and the version of Trimble Positions Desktop add-in or Pathfinder Office® that you have installed to your computer. You will also need to make sure that the version of Positions ArcPad Extension is compatible with your GPS unit. You can check the [compatibility chart](#) for assistance. If you need to install the Trimble Positions Desktop add-in, please see the support note [Installing Trimble Positions Desktop Add-in](#).


To install the Trimble Positions ArcPad Extension:

1. Download the Trimble Positions ArcPad extension from the [Trimble website](#). You will need full administrative rights to your computer while installing this software.
2. If you have an older version of Trimble Positions ArcPad extension or any version of GPSCorrect™ installed, you must uninstall it before starting a new installation process for Positions ArcPad extension. You can uninstall the software by going on the GPS unit to *Start> Settings> System> Remove Program* then select the software and press the Remove button. For Windows® 7 devices, go to *Start> Control Panel> Programs and Features* then select the software and press the Uninstall button.
3. You will also need to have the correct version of ArcPad installed prior to installing the Trimble Positions ArcPad extension.
4. Run the installation file that you just downloaded from the Trimble website. Follow the on-screen instructions to install the Trimble Positions ArcPad extension.

To activate Trimble Positions ArcPad Extension:

Use the Trimble Positions ArcPad extension Activator under *Start > All Programs> Trimble> Trimble Positions ArcPad extension* to license the extension.

1. Insert your Trimble Positions ArcPad extension installation code and select *Next*.
2. Choose the option *I wish to activate Trimble Positions ArcPad extension over the Internet* and select *Next*.
3. The activator should now contact the Trimble License Server and activator you license and then you will get a message that you license was successfully activated.



P. O. Box 31, Jerome, ID 83338

Ph: (208) 324-8006 Fax: (208) 324-8015 www.elecdata.com support@elecdata.com

Note: You can find your installation codes registered to your Trimble account [here](#). You will only have a POPN from the initial software purchase. Once you have registered your POPN, it is voided and you are given the installation code for future installation.

You will need to have ActiveSync® (Windows XP) or Windows Mobile Device Center (Windows 7 or Vista) installed in order to connect your GPS device to your computer. You can find the downloads for those [here](#).

If you have any complications getting the software installed, please contact your sales rep or email support@elecdata.com.